

INSTRUCTIONS MIP Hex Drivers™/MIP Speed-Tip Drivers™

Part Number 01-356 rev.1 Product Series #9000, et al and #9000S, et al

MOORE'S IDEAL PRODUCTS LLC 830 WEST GOLDEN GROVE WAY COVINA CA 91722 PH: 626 339 9007

Our MIP Drivers™ are handy tools for small hobby screws. We have designed our drivers to meet the needs of RC Racers since 1997. Please completely read all the tips before using your new MIP Driver.

TIPS:

- 1. Never use your MIP Driver™ to pry or over torque. This will bend and break the driver tip. MIP Drivers™ are designed for tightening and removing screws only!!
- 2. Only use MIP Speed Drivers™ in power tools with an adjustable clutch. Your power tool handle will over torque the Speed Driver which could break the tip. Be sure to set power tool clutch loose enough to lightly tighten screws. Use your MIP Hex Driver™ (hand tool) to finish tightening or to loosen screws.
- 3. MIP stand behind every wrench! MIP quality assurance promises that all wrenches are free from defects in workmanship. In the rare case that a defect is found, racers can get defective MIP Hex Drivers and MIP Speed Tip™s replaced for \$15.00 each including Continental USA shipping. Hawaii and International customers pay just \$20.00, including shipping. Send them directly into the MIP factory, include your email, name, full address, phone#, and U.S. money order or credit card information. Due to the nature of normal use of tools, wrenches broken by the customer, altered, or misused will not be replaced. All replacements are subject to inspection and are at the discretion of MIP.
- 4. Remember to work safe! Always wear appropriate eye and hand protection when using hand tools.

Thank you for choosing MIP!

www.miponline.com