

## **THROTTLE ARM**

### **ZENOAH® G23, G38, G45, AND G62**

This package contains the nylon throttle arm and screw to attach the arm to the throttle shaft of the carburetor.

- Step 1. Use needle-nose pliers to remove the metal throttle arm from the carburetor throttle arm shaft. Remove the spring from the throttle arm shaft and lay aside, it will not be used.
- Step 2. It may be necessary to remove the idle adjust Screw housing on some engines before mounting the nylon throttle arm. This will allow for clearance when mounting the nylon throttle arm.
- Step 3. Mount the nylon throttle arm to the throttle shaft of the carburetor and tighten the screw after you have adjusted the throttle arm for full travel. Reattach the idle adjust screw housing.
- Step 4. We recommend using a ball link to attach the Throttle arm to the throttle servo.